

# INSTAL MANUAL LIGHTS FOR ROOF RACK SYSTEM

## THANKS A LOT

Thank you for choosing products from Strands lighting division. We have everything for work vehicles, and you can find more information about our systems and products on our website. Feel free to contact our sales staff at [strandseurope.com](http://strandseurope.com). if you have any questions.

*Please note that the following instructions provide only a general assembly guide. Make sure to read the complete assembly manual specific to your model.*

## KEEP IN MIND

Please read and understand all instructions before installing this product. By installing this roof bar, you assume full responsibility for its proper and secure attachment to your vehicle. Improper installation could result in damage to your car, the roof bar, or items being transported, and may cause injury. The manufacturer and seller are not liable for any damages or injuries that may occur due to incorrect installation or misuse of this product. Use this product at your own risk.

## TOOLS YOU NEED

- SCISSORS/KNIFE
- HEX KEY SET
- MEASURE TAPE



1. When you have removed the bottom rubber strips find you hardware that comes with the kit.



2. The kit includes all the components you need. If you ordered the kit without the directional warning lights, you can purchase them separately on our website. An extension cable is provided for those who only have the endcaps.



3. Connect all the cables together. Be sure to screw the connections tightly to prevent water from entering the connectors.



5. Install the directional warning lights first. If there is any excess cable, you can bend it back on itself to fit it neatly.



6. Mount the feet onto the rail by sliding them in from one side.



7. If you need more space for the connecting cable from the other lights, you can feed it through this hole.



7. Mount the endcaps.



**8.** Secure the endcaps so they are tight against the frame. Leaving a gap between the frame and the light may cause extra wind noise while driving.



**9.** Measure and ensure the mounting feet are in the correct location. This will vary by vehicle, so we recommend a dry fit on the roof using the rubber feet supplied in the kit. If this step is not performed perfectly, it will leave gaps in the rubber strips.



**10.** Secure the feet in place with a torque of 5 Nm.



**11.** Secure the directional warning lights with a torque of 5 Nm.



**12.** Cut the strips to the correct length and place them in the slot.

**FINISH!**

