

OTHER ARTICLES IN THE LIGHTNING-FAMILY:

Complete kits

Analog Lightning 3025 Minus (65-3025M)

Analog Lightning 3025 Plus (65-3025P)

Analog Lightning Reverse 2025 Plus (65-2025P)

Digital Lightning 1200 (65-1200)

Additional adaptercables:

Adapter 1xFLH 9,5 to 1x3-pole DTP (65-1700-13DTP)

Adapter 1xFLH 9,5 to 2x2-pole (65-1700-22DT)

Adapter 1xFLH 9,5 to 2x3-pole (65-1700-23DT)

Adapter 1xFLH 9,5 to 2x4-pole (65-1700-24DT)

Adapter 1xFLH 9,5 to 3x2-pole (65-1700-32DT)

Adapter 1xFLH 9,5 to 3x3-pole (65-1700-33DT)

Adapter 1xFLH 9,5 to 3x4-pole (65-1700-34DT)

Adapter 1xFLH 9,5 to 4x2-pole (65-1700-42DT)

Adapter 1xFLH 9,5 to 4x3-pole (65-1700-43DT)

Adapter 1xFLH 9,5 to 4x4-pole (65-1700-44DT)

Adapter DT 1x2-pole to 1x3-pole (65-DT1213)

Adapter DT 1x2-pole to 1x4-pole (65-DT1214)

Adapter DT 1x2-pole to 2x2-pole (65-DT1222)

Adapter DT 1x2-pole to 2x3-pole (65-DT1223)

Adapter DT 1x2-pole to 2x4-pole (65-DT1224)

Adapter DT 1x2-pole to 1x2-pole Superseal (65-DT12SS12)

Modernum AB

visiting/postal address:

Johanneslundsvägen 12, SE-194 61 Upplands Väsby

telephone: +46 8 626 95 00

e-mail: info@modernum.se

web: www.modernum.se

2023.01.24




65-1700-AH

Auxiliary Lightning Amp Harness

This harness enables you to add a high Amp additional LED light bar or other external light. The harness can be used with any of our Analog or Digital Lightning.



Support:
+46 8 626 95 00
info@modernum.se



Note: Use correct fuse according to the power of the auxiliary lights.

NOTE I: Please remove the relay from the socket before connecting the FASTON terminal (FLH 9.5) to the socket.

NOTE II: Make sure to use correct fuse according to the power of the auxiliary lights.